

**OPTION WITH
TEPPANYAKI 58**



Put frame 58 in bilba (left or right)



Put smaller frame 40 on right side of bilba



- Put subfiller in teak, 5 or 7cm – depending on cooking plate - in between the frames



- Put granite/wood in the bilba between the frames



- Put your cooking plate on the right side in the adapted frames



Put teppanyaki 58 in frame 58

* Gazz grill does not need any frame



Ready to cook

OPTION

3 x ZONES 40

OR

2x ZONES 40 + 1x ZONE 38



Put frame 38 or 40 in bilba (left or right)



Put smaller frame 40 in the middle of the bilba



Put subfiller in teak, 5 or 7cm – depending on cooking plate - in between the frames



Put smaller frame 40 in the middle of the bilba




Put subfiller in teak, 5 or 7cm – depending on cooking plate - in between the frames



Put teppanyaki 38 in correct frame 38



Put cutting board in frame 40



Put cooking plate in frame 40



Ready to cook

(40x40x40 – 2x5cm teaksubfiller ex.
Multiflex + cuttingboard + wok)

40x40x38 – 1x5cm + 1x7cm teak subfiller



40x40x38 – 1x5cm + 1x7cm teak subfiller

